HT-2333BK

User Manual

Before you proceed with the installation, please notice the following descriptions.

Note 1: The following installation was operated under Windows XP. (Procedures are similar for Windows 98SE/Me/2000.)

Note 2: If you have installed the WLAN USB driver & utility before, please uninstall the old version first.

Note 3: Double Click the RTL8187B CD-ROM and click

setup.exe to begin installation

1. Installation

1. If you insert the Wireless LAN USB Adaptor into your computer USB port after ``installing the software program from the CD, then the following window pops up.
2. Click **Cancel**.

Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
This wizard helps you install software for:
Wireless LAN USB Adaptor
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

3. Choose a set up language.
4. Click **Next** to process the installation. .




REALTEK USB Wireless LAN Driver and Utility
REALTEK USB Wireless LAN Driver and Utility
The InstallShield Wizard will install REALTEK USB Wireless LAN Driver and Utility on your computer. To continue, click Next.
< Back
Next >
Cancel

6. Click install to WLAN USB adaptor installation.


REALTEK USB Wireless LAN Driver and Utility
REALTEK USB Wireless LAN Driver and Utility
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel

7. On Windows Logo Software Installation screen, click **Continue Anyway** to continue.

Note: Not all the drivers will have this message box.

Software Installation
The software you are installing has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the software vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

8. Click **Finish** to complete the installation.

Wireless LAN Driver and Utility
InstallShield Wizard Complete
Setup has finished installing Wireless LAN Driver and Utility on your computer.
< Back
Finish
Cancel

9. After setup, restart your computer

Restarting Windows
Setup has finished copying files to your computer. Before you can use the program, you must restart your computer.
Choose one of the following options and click OK to finish setup.
Yes, I want to restart my computer now.
No, I will restart my computer later.
OK

2. Uninstallation

A. Uninstall the WLAN USB Adaptor Driver from “Wireless Network Driver and Utility” or “Control Panel”. Click “Uninstall” (or “Change/Remove”) to remove Wireless LAN USB Adaptor driver.

Wireless Network Driver and Utility
Wireless Network Driver and Utility
Uninstall
Wi-Set Wizard
Wireless Network Driver and Utility
Change or Remove Programs
Add New Programs
Add/Remove Windows Components
Currently installed programs:
Show updates
Sort by:
Name
NETGEAR JWAG511 54 Mbps A or G Wireless PC Card
Size 2.00MB
Wireless Network Driver and Utility
Size 3.68MB
Click here for support information.
Used occasionally
Last Used On 9/20/2005
To change this program or remove it from your computer, click Change/Remove.
Change/Remove
SigmaTel AC97 Audio Drivers
Size 0.09MB
TOSHIBA Hotkey Utility for Display Devices
Size 1.06MB
InstallShield Wizard
USB WLAN Driver and Utility Setup is preparing the InstallShield® Wizard, which will guide you through the rest of the setup process. Please wait.
Cancel

B. Click “OK” if you want to remove Wireless LAN USB Adaptor Driver .

C. Click “Finish” to complete the uninstallation.


Wireless Network Driver and Utility
Maintenance Complete
InstallShield Wizard has finished performing maintenance operations on Realtek RTL8187 Wireless Network Driver and Utility.
< Back
Finish
Cancel

Making a Basic Network Connection

In the following instruction for making a network connection, we use the utility we provided to configure your wireless network settings.

Note: For Windows XP users that want to configure your wireless network using this Utility, please perform the following procedures to disable your native Windows XP wireless support (Wireless Zero Configuration Service)

1. Double click the icon on your desktop to start the utility or in the task bar.



Ad-Hoc Mode

An Ad-Hoc mode wireless network connects two computers directly without the use of a router or AP. It is also know as a peer-to-peer network. For example, we can install this wireless adapter to two computers respectively. The communication between the two computers is an Ad-Hoc mode network.

Ad-Hoc Mode

To use this adapter in Ad-Hoc Mode

1. Double click the icon on your desktop to start the utility or in the task bar.

2. Click the **"Available Network"** button to scan available wireless network adapters. Double click on the network adapter that you are going to connect to.



3. Click the OK button to confirm that you are connecting to an open wireless network.



4. Click OK to add this network into the profile list.

Note: This example is an open wireless network. If you are going to connect to a Wireless adapter with security protection, you will have to configure the encryption settings in this profile to be corresponding to the other wireless adapter. Please click on the **"Network Authentication"** drop list to select an authentication method, and then select a **"Data encryption"** type. Fill in each required blanks and click **"OK"**.



Infrastructure mode

An Infrastructure Mode network contains at least one wireless client and one wireless AP or router. This client connects to Internet or intranet by communicating with this wireless AP.



Infrastructure Mode

To use this adapter in Infrastructure Mode:

1. Double click the icon on your desktop to start the utility or in the task bar.

2. Click the **"Available Network"** button to scan available access points. Double click on the AP that you are going to connect to.



3. Double click to create profile that you are connecting to an open wireless network.



4. Click **OK** to add this network into the profile list.



Note:

This example is an open wireless network. If you are going to connect to an AP with security protection, you will have to configure the encryption settings in this profile to be corresponding to your AP. Please click on the **"Network Authentication"** drop list to select an authentication method, and then select a **"Data encryption"** type. Fill in each required blanks and click **"OK"**.

Tip: Windows XP and Windows 2000 users is also allowed to connect to your wireless network with the "RT-Set" setup wizard. Please refer to **"Appendix"** for more information.

Introduction to the Wireless LAN Utility

Note: This management instruction uses Windows XP as the presumed operation system. Some functions are not supported in Windows 98se or Windows ME.

Starting the Wireless LAN Utility



You may click on the tabs above to configure this adapter. The checkboxes below provide the following functions:

Show Tray Icon	Check this checkbox to show the utility icon on your system tray, which is in the notification area at the lower-right corner of the windows desktop. You may also uncheck it to remove the utility icon from system tray.
Radio Off	Check this checkbox to prevent this adapter form transmitting or receiving signals. Uncheck it to communicate.
Disable Adapter	Check this checkbox to disable this wireless adapter. Uncheck it to enable this adapter again.

General

After starting the utility, the general page pops up This **General** tab provides the information of your current wireless network connection. You may click the **Renew IP** button to refresh those listed information.



Status:	Check if the device associated to target network.
Speed:	The current connection speed
Type:	Infrastructure mode or Ad-Hoc mode.
Encryption:	The performing encryption mode for connecting to current network profile.
SSID:	The SSID (network name) of the connected wireless network.
Signal Strength:	Indicates the signal strength detected by this adapter.
Link Quality	Indicates the link quality of this wireless connection.
Network Address:	Shows the current IP addresses settings for this adapter.

Profile

The **Profile** tab lists the preferred connections. You can click the buttons beside to do configure each connection.



Add Click this button to add a connection profile for this adapter.

Remove To remove a connection profile, click this profile on the profile list and click this button to delete it.

Edit To modify the configurations for a profile, click this profile on the profile list and click this button to edit.

Duplicate To make a copy of a profile, click the profile that going to be copied, and click this button to copy it.

Set Default To select a profile as your default wireless connection, click this profile on the list and click this button. You may also double click on each profile to select it as your default wireless connection.

Available Network

This available tab lists the reachable wireless network of this adapter.



Refresh Click this button to rescan available networks around the adapter.

Add to Profile To add an available Network to your profile list, select an available network and click this button to add.

Advanced

This Advanced tab provides advanced configurations to this adapter. Every modification in this tab will be performed after clicking the **Apply** button.
To restore the default settings of the advanced tab, click the **Set defaults** button to perform restoring.



Power Save	
None	Disable Power saving function.
Min	Minimum power consumption
Max	Maximum power consumption
Turbo Mode	
OFF	Disable turbo mode
ON	Enable turbo mode
AUTO	Enable or disable turbo automatically according to the detected environment
Fragment Threshold	
The maximum size of a packet that is going to be segmented and transmitted. Select the size from 256 to 2432(default) bytes.	
RTS Threshold	
Select the RTS Threshold form 0 to 2432(default)	
Wireless Mode	
802.11g/b	Connect to a 802.11b/g network (2.4GHz/54Mbps)
802.11b	Connect to a 802.11b network (2.4GHz/11Mbps)

802.11b Preamble Mode
Select the preamble mode to be long, short or auto detection mode.
Channel Plan
Select your region from the drop list. Please note that it is necessary for you to select a correct region. Selecting an incorrect region may again the applicable law.
PSP XLink Mode
If you are using the PS2 or X-box for wireless connection
WMM Parameter
Quality of Service for better streaming bandwidth control

Status

This tab shows the current connection status of this adapter.



Statistics

See this tab to show the transmission activity record. Clicking the **“Reset”** button recounts the values from zero.



AP mode management guide

General

After configuring the adapter in AP mode, this "**General**" page shows up, which shows the general information of this AP.

SSID:	The SSID (network name) of the wireless network constructed by this AP.
BSSID:	The MAC address of this AP
Config:	Click this button to change configurations to this AP
Association Table:	Shows the information of those devices that associated with this AP including their MAC addresses and the time that they connected with this device.



Advanced

Beacon Interval:	Define the interval between beacons from 20~1000
DTIM Period:	Set the DTIM period between 1~255
Preamble Mode:	Click the drop list to select the preamble to be long, short or auto
Set Defaults:	Click this button to restore the settings above to default
Apply:	Click this button to execute changes.



Statistics

See this tab to show the transmission activity record. Clicking the **"Reset"** button recounts the values from zero.


REALTEK USB Wireless LAN Utility
Refresh(R) Set Wizard(S) Mode(M) View(V) About(A)
MyComputer
Realtek RTL8187B W
General Advanced Statistics ICS
Counter Name Value
Tx OK 2091
Tx Error 0
Rx OK 28
Rx Packet Count 28
Rx Retry 1
Rx ICV Error 0
Reset
Show Tray Icon
Disable Adapter
Close
Radio Off
Ready
NUM

Internet Connection Sharing (ICS)

This page allows users to select the adapter for connect to public network.
Please click on the device that are used for connecting to public network and click the “Select” button, and then click the “Apply” button to execute.